



Item no: TUW-3220

WELDING GAGE:

Changes from standard to metric, simply remove gauge body, turn scale over and replace body.

Measure internal misalignment

Measure fit-up gap

Measure bevel on end preparation

Measure the crown height of the butt welds

Measure fillet weld size

Measure scribe line, socket welds

Measure pipe wall thickness

Can be calibrated to NBS standard